

Controlling the Thermostat (AC)

Customer Service - 2025-01-18 - Comments (0) - Pompano Pool retreat

Thermostats don't have a touch screen. Use the touch bar on the right side to control your thermostat. Swipe up to raise the temperature, swipe down to lower it, and tap to confirm. The display will show you how many minutes until your desired temperature is reached.

- Tap the touch bar to bring up the menu.
- Swipe up or down to select an option.
- Tap the touch bar again to confirm your selection.



On the thermostat

Depending on the thermostat model, please adhere to the following instructions.



Nest Thermostat:

Set to **Heat**, **Cool**, **Heat • Cool** or **Eco** mode

1. Tap the touch bar to open the Menu view.
2. Slide your finger to **Temperature mode**, then tap to select.
3. Slide your finger to the mode you want, then tap to set it.

Set to **Off** mode

1. Press and hold the touch bar until "Turn off" appears on the screen.
2. Slide the touch bar to highlight **Turn off** > tap the touch bar to select.




Nest Thermostat E:

1. Press the thermostat ring to open the Quick View menu.
2. Turn the ring to the mode you want, then press to select it.



Nest Learning Thermostat:

1. Press the thermostat ring to open the Quick View menu.
2. Turn the ring to **Mode**  and press to select.
3. Turn the ring to choose a mode, then press to activate it.
4. Press again to confirm.